

Model	70	100	120
Nominal load (kW)	70	98	119
Air volume (m ³ /h)	5000	6500	6500
Current (A)	2.09	2.70	2.70
Gas consumption G31 (kg/h)	5.4	6.5	8.1
Gas type G31	propane	propane	propane
Gas consumption G20 (m ³ /h)	7.76	11.08	13
Gas type G20	natural gas	natural gas	natural gas
Power consumption (W)	480	620	620
Supply voltage (V)	230	230	230
Rotation speed (RPM)	1290/1509	1350/1650	1350/1650
Frequency (Hz)	50/60	50/60	50/60
Air throw (m)	35	40	40
Heater size & weight information			
Weight per complete unit (kg)	42	48	48
Height (cm)	58	62.4	62.4
Length (cm)	110.5	115.2	115.2
Width (cm)	63.7	68.9	68.9
Minimum clearance to combustibles			
Sides of heater (cm)	100	100	100
Air inlet heater (cm)	100	100	100
Air outlet heater (cm)	300	300	300

The policy of Roxell is one of continuous product improvement. We reserve the right to alter specifications without prior notice. Heating products should be installed only in accordance with local laws, codes and regulations. These products are not for residential use, for agricultural use only. Gas pipe layout assistance is available to customers through authorized distributors. Specific, certified models are available for various countries, where required. Customer/ distributor need to check if Roxell has a certified model for the country of installation. All models meet stringent standards for low carbon monoxide.

Model	8 l	10 l	12 l
Nominal load (kW)	80	100	120
Air volume (m ³ /h)	7700	7700	7700
Current (A)	5.1	5.1	5.1
Fuel consumption (l/h)	8	9.6	12
Fuel type	oil	oil	oil
Power consumption (W)	1150	1150	1150
Supply voltage (V)	230	230	230
Rotation speed (RPM)	1400	1400	1400
Frequency (Hz)	50/60	50/60	50/60
Air throw (m)	40	40	40
Heater size & weight information			
Weight per complete unit (kg)	47	47	65
Height (cm)	59.1	59.1	59.1
Length (cm)	126.8	126.8	136.8
Width (cm)	66.4	66.4	66.4
Minimum clearance to combustibles			
Sides of heater (cm)	100	100	100
Air inlet heater (cm)	100	100	100
Air outlet heater (cm)	300	300	300

The policy of Roxell is one of continuous product improvement. We reserve the right to alter specifications without prior notice. Heating products should be installed only in accordance with local laws, codes and regulations. These products are not for residential use, for agricultural use only. Gas pipe layout assistance is available to customers through authorized distributors. Specific, certified models are available for various countries, where required. Customer/ distributor need to check if Roxell has a certified model for the country of installation. All models meet stringent standards for low carbon monoxide.