

Model	70	100	120
Nominal load (BTU/h)	238,910	334,389	409,560
Air volume (CFM)	2943	3826	3826
Current (A)	2.09	2.70	2.70
Gas consumption G31 (gal/h)	2.80	3.37	4.19
Gas type G31	propane	propane	propane
Gas consumption G20 (ft ³ /h - CFH)	274	391.3	459.1
Gas type G20	Natural gas	natural gas	natural gas
Power consumption (W)	480	620	620
Supply voltage (V)	230	230	230
Rotation speed (RPM)	1290/1509	1350/1650	1350/1650
Frequency (Hz)	50/60	50/60	50/60
Air throw (ft)	115	131	131
Heater size & weight information			
Weight per complete unit (lb)	92.4	105.6	105.6
Height (in)	22.8	24.4	24.4
Length (in)	43.7	45.3	45.3
Width (in)	25.2	27.2	27.2
Minimum clearance to combustibles			
Sides of heater (in)	39.4	39.4	39.4
Air inlet heater (in)	39.4	39.4	39.4
Air outlet heater (in)	118	118	118

The policy of Roxell is one of continuous product improvement. We reserve the right to alter specifications without prior notice. Heating products should be installed only in accordance with local laws, codes and regulations. These products are not for residential use, for agricultural use only. Gas pipe layout assistance is available to customers through authorized distributors. Specific, certified models are available for various countries, where required. Customer/ distributor need to check if Roxell has a certified model for the country of installation. All models meet stringent standards for low carbon monoxide.

Model	8 l	10 l	12 l
Nominal load (BTU/h)	272,971	341,300	409,560
Air volume (CFM)	4532	4532	4532
Current (A)	5.1	5.1	5.1
Fuel consumption (gal/h)	2.1	2.54	3.17
Fuel type	oil	oil	oil
Power consumption (W)	1150	1150	1150
Supply voltage (V)	230	230	230
Rotation speed (RPM)	1400	1400	1400
Frequency (Hz)	50/60	50/60	50/60
Air throw (ft)	131	131	131
Heater size & weight information			
Weight per complete unit (lb)	103.4	103.4	143
Height (in)	23.2	23.2	23.2
Length (in)	50	50	54
Width (in)	26	26	26
Minimum clearance to combustibles			
Sides of heater (in)	39.4	39.4	39.4
Air inlet heater (in)	39.4	39.4	39.4
Air outlet heater (in)	118	118	118

The policy of Roxell is one of continuous product improvement. We reserve the right to alter specifications without prior notice. Heating products should be installed only in accordance with local laws, codes and regulations. These products are not for residential use, for agricultural use only. Gas pipe layout assistance is available to customers through authorized distributors. Specific, certified models are available for various countries, where required. Customer/ distributor need to check if Roxell has a certified model for the country of installation. All models meet stringent standards for low carbon monoxide.